

Plug-in Vision Series Automatic Timer Instruction Addendum

Thank you for your order with our new Auto On capability!
Please find instructions below for operation of this function.

- Use the Auto On buttons (ON 3hr / 6hr / 9hr) to set your fixture to turn on for the described duration at the current time each day.
- To disable the Auto On timer, hold the red Off button (O) until the fixture blinks 3x times. This is the ONLY way to disable the Auto On timer. Note that the fixture can be on or off during this process.
- You can, however, program a replacement Auto On timer via the Auto On buttons. This allows you to change both the start time and duration without first disabling the timer. Selecting a new Auto On timer button will overwrite the existing timer.
- You can use the Off timer buttons (OFF 3hr / 6hr / 9hr) independently of the Auto On timer. Should you have an Auto On timer set and select an Off timer option, your fixture will turn off automatically at the described duration of the Off timer selection, though will still turn on the following day at the time previously set via the Auto On timer.
- You can use these Off timer buttons or quick-press the red Off button to modify the time your fixture will turn off without impacting the Auto On timer. You can also use the red On button (|) at any point without impacting the Auto On timer.
- Brightness and color temperature settings are stored on a last used basis. When the fixture turns off, it will turn back on with the same brightness and color temperature settings as previously used.

